



## Set up and Secure Internet steps for Photon

1. [Initial Set up for Postpay Wi-Fi](#)
2. [Initial Set up for Prepay Wi-Fi](#)
3. [Initial Set up for Postpay \(Whiz, Plus, Max\)](#)
4. [Initial Set up for Prepay \(Whiz, Plus, Max\)](#)
5. [Secure internet for Wi-Fi \(Plus, Max, 3G\)](#)

## 1. Initial Set up for Post pay Wi-Fi

1. Plug-in your Photon to Laptop/Desktop.
2. Defaults URL opens or go to <http://192.168.1.1>.
3. Go to **OTA**. For logging in enter User name and Password both as **admin**. If not asked for any user name & password, continue to the next step.
4. Select **Postpaid** and click on **Activate**. Your Photon Wi-Fi is now ready to be used on 5 devices with default Wi-Fi Password as **12345678**. Please change this password immediately in order to prevent misuse.
5. If activation fails, click on **Activate** again.

## 2. Initial Set up for Prepay Wi-Fi

1. Plug-in your Photon to Laptop/Desktop.
2. Defaults URL opens or go to <http://192.168.1.1>.
3. Go to **OTA**. For logging in enter User name and Password both as **admin**. If not asked for any user name & password, continue to the next step.
4. Select **Prepaid** and click on **Activate**. Your Photon Wi-Fi is now ready to be used on 5 devices with default Wi-Fi Password as **12345678**. Please change this password immediately in order to prevent misuse.
5. If activation fails, click on **Activate** again.

## 3. Initial Set up for Post pay (Whiz, Plus, Max)

1. Plug-in your Photon to Laptop/Desktop.
2. Auto popup would come to install the required dialer software, else you may go to **My Computer** and install manually.

3. Once the dialler is successfully installed, click on Network Settings and select Network mode as **Whiz** and click on **Ok** and save.
4. Click on **Activate** option in dialler.
5. Select **Postpaid** and click on **Activate**.
6. After successful activation change the network mode to **Hybrid**.
7. If activation fails, click on **Activate** again.

#### 4. Initial Set up for Pre pay (Whiz, Plus, Max)

1. Plug-in your Photon to Laptop/Desktop.
2. Auto popup would come to install the required dialer software, else you may go to **My Computer** and install manually.
3. Once the dialler is successfully installed, click on Network Settings and select Network mode as **Whiz** and click on **Ok** and save.
4. Click on **Activate** option in dialler.
5. Select **Prepaid** and click on **Activate**.
6. After successful activation change the network mode to **Hybrid**.
7. If activation fails, click on **Activate** again.

#### 5. Secure internet for Wi-Fi

1. Plug-in your Photon to Laptop/Desktop.
2. Go to <http://192.168.1.1>
3. Go to **OTA**. For logging in enter User name and Password both as **admin**. If not asked for any user name & password, continue to the next step.
4. Go to WLAN Basic Settings. In WPA pre-shared key, enter the new password.